

ELKAY® BIM Content Library

User Guide – Coolers and Fountains -

Products ➤ Drinking Water ➤ Coolers and Fountains ➤ On Wall



EZSTL853JOC5A



EZSTL8L2JOC



EZSTL852JOC



LZOSTL8L2JOC



LZOSTL8L3JOC



LZOSTL852JOC



LZOSTL853JOC



LZOSTL853JOC5A



LZSTL8L2JOC



LZSTL852JOC



LZSTL853JOC5A

Figure 1: EZ Family

LOADING THE MODELS

How to Load the Elkay Family

It is recommended the steps outlined below are followed to properly load the BIM component into a project.

1. Open a Revit Project File (.RVT) and navigate to the Plan View.
2. Go to the 'Insert' tab on the Revit ribbon and select 'Load Family'




Figure 2: Loading the Family into a Project

3. Navigate to the location of the downloaded Elkay Coolers and Fountains (RFA file)
4. Click 'OK' to load the component into the project

The family is now copied and embedded into the project. It can be selected from the components button located on the 'Architecture' tab on the main Revit Ribbon.

ACCESSING PRODUCT INFORMATION

How to Access the Data for the EZ Family

To access the data embedded into the component, simply select the desired component and click the 'Edit Type' button at the head of the 'Properties' bar. This is typically located on the left-hand side of the screen.

BIM File Name: Elkay_Drinking-Water_Coolers-and-Fountains_EZ_Onwall_St2_Asiapac.rfa




Figure 3: Accessing Additional Data

Master BIM Model : Elkay_Drinking-Water_Coolers-and-Fountains_EZ_Onwall_St2_Asiapac.rfa

SKU's List in BIM

Type Properties

Family: **Elkay_Drinking-Water_Coolers-and-Fountains_EZ_Onwall_St2_Asiapac**

Type: **EZ07L833OC5A**

Type Parameters:

Construction	EZ07L833OC
Special Feature	EZ07L833OC5A
Finish	EZ07L833OC
Power	EZ07L833OC5A

Subtitle Style: **EZ07L833OC**

Activation by: **Flow Guard # Safety Bubbler**

Mounting Type: **Wall Mount (On Wall)**

Chilling Capacity: **5 GPH**

Full Load Amps: **2.0**

Rated Watts: **170**

Dimensions (L x W x H): **36-3/4" inch x 19 inch x 25-5/16 inch**

Approx. Shipping Weight: **72 lbs**

Installation Location: **Indoor**

Number of Stations: **2**

Materials and Finishes:

Exterior Finish	304 Stainless Steel
Material Finish	304 Stainless Steel

Mechanical:

WPU	
HWPU	
CWPU	


Modeling Data:

Type Image	
Keynote	
Model	EZ07L833OC5A
Manufacturer	Elkay
Type Comments	
URL	

What do these arrows mean?

< Previous OK Cancel Apply

SKU's Configured BIM Model



LOADING THE IFC MODEL


How to Load the Elkay IFC Model in Revit

To use an ELKAY IFC model, link the IFC file to a Revit model.

1. (Optional) Before linking an IFC file, click File tab ➤ Open ➤  (IFC Options) and use the Import IFC Options dialog to do the following:

- Select a default Revit template to use for IFC files.

Note: If a default template is not selected, the first template listed under File Locations in Revit Options will be used.

2. Open the Revit model.
3. Click Insert tab ➤ Link panel ➤  (Link IFC).
4. In the Open IFC File dialog, navigate to the IFC file, select it, and click Open.